1. Test fit blade to wheel before removing backing tape. Get a feel for guide lip resting on edge of your wheel. If they don't feel or look correct contact-RimBladesUSA.com for guidance. We accept returns and exchanges.
2. Clean your wheel lip with Mr. Clean Magic Eraser and Dawn Dish Soap. (Not provided in kit. This step will remove any tire shine or waxes that will prevent a proper bond.)
3. Clean lip of wheel with provided alcohol wipe and let dry.
4. Wipe lip of wheel with provided 3M Adhesive Primer. Let dry for 3-5 minutes. Do not let sit for more than 20 minutes.

5. Remove 1 inch of backing tape.
6. Stick first inch to lip of wheel.
7. Use guide lip of the RimSaver to align before removing more backing tape. (Don't rush! Align the blade and pull tape from under after placed.) Continue around the wheel. If the bottom section is difficult you can pull can forward so you are working at top of wheel.
8. Leave 1 inch of backing tape installed prior to cutting overlap.

9. With sharp scissors cut the overlap long. Trim as needed to get a good seam.
10. Once desired seam is cut remove the remaining backing tape.
11. Use towel to put pressure on blade to seat the adhesive. Work all around the lip of wheel. This step should be repeated on all wheels in 24 hrs.

12. Optional step- Use provided Super Glue and coat back of provided clip. Place clip over the seam and press down for 20 seconds.
13. Take pictures of your new RimSavers and upload them on RimBladesUSA.com. We want to show off your ride.

**RimBladesUSA guarantees our products. Even if you mess up on install. Email orders@rimbladesusa.com and we will work with you to resolve the problem. Customer Satisfaction is #1! ALOHA**